



INSTALLATION INSTRUCTIONS


Accessory
BODY SIDE MOLDINGS

Application
2022 CIVIC

Publications No.
All
Issue Date
JUN 2021

GENERAL VIEW

If you are also installing door edge guards (sold separately) or door edge films (sold separately), install them before you install the body side moldings.



QK30201AU

FOR YOUR SAFETY (Read carefully.)

Warning Symbols

Safety: Your safety, and the safety of others, is important. To help you make informed decisions about service procedures, we have provided safety messages where appropriate. Of course, it is not practical or possible to warn you about all the hazards associated with servicing a vehicle - you must use your own good judgment.

You will find important safety messages preceded by one of following symbols:

*All symbols are not used in all installation instructions.

⚠ DANGER

You will be killed or seriously hurt if you do not follow the instructions.

⚠ WARNING

You can be killed or seriously hurt if you do not follow the instructions.

⚠ CAUTION

You can be hurt if you do not follow the instructions.

NOTICE

Gives advice to prevent damage to the product, vehicle, the environment or other property.

NOTE

Gives helpful information or instructions to be followed when installing this product.




Indicates a prohibited action.


Procedure and Location Icons

These icons indicate the work location and the worker's point of view.

*All icons are not used in all installation instructions.



The location on the vehicle.



The location in the vehicle.
(instrument panel.)



Wear eye protection.



Wear heavy gloves.



Use an assistant.



Place the part on a blanket.



Work perpendicular.



Remove any burrs.



Use touch-up paint and allow to dry.



Tighten to the specified torque.



Apply firm pressure while rolling, especially at the ends, to set the adhesive.



Press firmly.



Clean with isopropyl alcohol.



Return the original part to the customer.
(Do not reuse.)

Safety: General

- Be careful not to damage the vehicle or the parts.
- The illustrations may differ slightly from the actual accessory.







Safety: Accessory

- Always use the parts and tools specified in the installation instructions.
- Do not install the accessory on a dirty surface or in direct sunlight.
- Make sure the ambient air temperature is 60°F (15°C) or above when installing accessories that use adhesive material.

- When pressing the accessory firmly with the palm of your hand, be careful not to damage it or the vehicle.
- When applying adhesive material, make sure it is lined up properly before attaching. Once the adhesive material touches the surface, do not try to remove it. If you do, you could damage the part.
- Do not wash the vehicle for 24 hours to allow the adhesive to cure.

PARTS LIST

Body side moldings Kit (P/N 08P05-T20-100)

Left front molding (Identification mark: FR-L)	Right front molding (Identification mark: FR-R)	Left rear molding (Identification mark: RR-L)	Right rear molding (Identification mark: RR-R)
			
Template 	Alcohol wipes (4) 		

REQUIRED TOOLS AND SUPPLIES


Masking tape

The following tool is available through the Honda Tool and Equipment Program:

Rubber Roller (T/N NHLE54D)


INSTALLATION

1. Fold the tabs.



QK30202DU


2. Secure the template.



3. Clean the attaching area.

NOTE

Allow to dry thoroughly.




QK30214AU

4. Temporarily attach the adhesive backings.

NOTE

Make sure to check the identification mark before installation.

2 ADHESIVE BACKINGS (Attach.)



MASKING
TAPE

2 ADHESIVE BACKINGS (Remove.)



LEFT FRONT
MOLDING
(Identification mark:
FR-L)



QK30205AU

5. Remove the adhesive backings.
6. Choose one of these options.

- | | |
|---|--------------|
| • With door edge guards or door edge films | Go to step 7 |
| • Without door edge guards or door edge films | Go to step 8 |

7. Line up the left front molding.


Line up with the tip of the arrow.



QK30206EU


Go to step 9

8. Line up the left front molding.




QK30213BU

9. Secure the left front molding.



QK30207CU

10. Secure the left front molding.




QK30208CU

11. Temporarily attach the adhesive backings.



NOTE

Make sure to check the identification mark before installation.




QK30209AU

12. Remove the adhesive backings.
13. Line up the left rear molding.




LEFT REAR
DOOR

TEMPLATE




QK30210EU

14. Secure the left rear molding.




QK30211CU

15. Secure the left rear molding.



QK30212CU

16. Remove the template.
17. Flip the template.
18. Repeat the same procedures on the other side.



Q9D1014AM

19. Check that all parts are installed properly.