<u>www.collegehillshonda.com</u>

INSTALLATION INSTRUCTIONS

Accessory

ALL-SEASON FLOOR MATS P/N 08P17-TRT-100 Application

2020 CLARITY
(All Clarity Vehicles)

Publications No. VERSION 1

Issue Date
DEC 2019

PARTS LIST

Driver's all-season floor mat



Passenger's all-season floor mat




Left rear all-season floor mat



Right rear all-season floor mat



Illustration of the All-Season Floor Mats Installed in the Vehicle



INSTALLATION


NOTE:

- Before installing the mats, identify their installation positions.
- Connect the mats to the anchors to prevent the mats from sliding forward and possibly interfering with the pedals.
- If you remove a mat, make sure you re-anchor it when you put it back in your vehicle.
- If you replace a mat, use a factory mat designed to be used with the anchors.
- If you use a non-factory mat in the driver's footwell, make sure it fits properly and that it can be used with the anchors.
- Do not put an additional mat on top of the anchored mat. An additional mat may slide forward and possibly interfere with the pedals.

www.collegehillshonda.com


Installing the All-Season Floor Mats

1. Remove the floor mats as shown.




2. Place the grommets in the driver's all-season floor mat over the anchors. Push the grommets into the anchors to secure the retaining tabs, then turn the knobs 90° to secure the driver's all-season floor mat.

 Place the grommets in the passenger's all-season floor mat over the anchors. Push the grommets into the anchors to secure the retaining tabs, then turn the knobs 90° to secure the passenger's all-season floor mat.



www.collegehillshonda.com

4. Place the grommets in the left rear all-season floor mat over the anchors. Push the grommets into the anchors to secure the retaining tabs, then turn the knobs 90° to secure the left rear all-season floor mat.



 Place the grommets in the right rear all-season floor mat over the anchors. Push the grommets into the anchors to secure the retaining tabs, then turn the knobs 90° to secure the right rear all-season floor mat.

