

# Germain Honda of College Hills




## INSTALLATION INSTRUCTIONS

Accessory  
**AMBIENT LIGHTS**

Application  
**2023 CR-V  
MODEL SERIES**

Publications No.  
**VERSION 1**  
Issue Date  
**AUG 2022**

### GENERAL VIEW



QL00622AB

### FOR YOUR SAFETY (Read carefully.)

#### Warning Symbols

**Safety:** Your safety, and the safety of others, is important. To help you make informed decisions about service procedures, we have provided safety messages where appropriate. Of course, it is not practical or possible to warn you about all the hazards associated with servicing a vehicle - you must use your own good judgment.

You will find important safety messages preceded by one of the following symbols:

\*All symbols are not used in all installation instructions.

**⚠ DANGER**

You will be killed or seriously hurt if you do not follow the instructions.

**⚠ WARNING**

You can be killed or seriously hurt if you do not follow the instructions.

**⚠ CAUTION**

You can be hurt if you do not follow the instructions.

**NOTICE**

Gives advice to prevent damage to the product, vehicle, the environment or other property.

**NOTE**

Gives helpful information or instructions to be followed when installing this product.



Indicates a prohibited action.

# Germain Honda of College Hills

## Procedure and Location Icons

These icons indicate the work location and the worker's point of view.

\*All icons are not used in all installation instructions.



The location on the vehicle.



The location in the vehicle.  
(Instrument panel.)



Wear eye protection.



Wear heavy gloves.



Use an assistant.



Place the part on a blanket.



Work perpendicular.



Remove any burrs.



Use touch-up paint and allow to dry.



Tighten to the specified torque.



Apply firm pressure while rolling, especially at the ends, to set the adhesive.



Press firmly.




Clean with isopropyl alcohol.




Return the original part to the customer.  
(Do not reuse.)


## Wire Harness Routing Precaution




Do not secure the accessory harness to the SRS harness. (except for instruction cases.)




Push the connectors and terminals together until they lock.



Do not pull the harness to unplug the connectors.



Install removed connectors in their original location.




Do not pull the harness.



Secure the accessory harness as shown.



Do not pinch the harness.



Cut off the excess wire tie.

# Germain Honda of College Hills

## Safety: General

- Observe all safety notes and precautions described in the service information, in addition to those described in this Installation Instruction. Be extremely careful for your safety and safety of others.
- Be careful not to damage the vehicle or the parts.
- Be extremely careful when handling retaining tabs and clips.
- Note the locations of the parts before removing them so they can be properly installed in their original positions.
- The illustrations may differ slightly from the actual accessory.

## Safety: Electric Parts









Always disconnect the negative cable from the battery before beginning work.

## Safety: Accessory

- Always use the parts and tools specified in the installation instructions.
- Do not install the accessory on a dirty surface or in direct sunlight.
- Make sure the ambient air temperature is 60°F (15°C) or above when installing accessories that use adhesive material.
- When pressing the accessory firmly with the palm of your hand, be careful not to damage it or the vehicle.
- When applying adhesive material, make sure it is lined up properly before attaching. Once the adhesive material touches the surface, do not try to remove it. If you do, you could damage the part.

## PARTS LIST

### Ambient Lights Kit (P/N 08E10-3A0-100)

Lights (2) 	Harness 	Wire ties (21) 	Wire ties with holder (2) 
Self-tapping screws (2) 	Washer-bolts (4) 	Template 	Fuse label 

# Germain Honda of College Hills

## REQUIRED TOOLS AND SUPPLIES

- Ratchet
- Shop towel
- Isopropyl alcohol
- Torque wrench
- Eye protection (face shield, safety goggles, etc.)
- Drill
- 10 mm Socket
- Masking tape
- Diagonal cutters
- File
- 3 mm, 5 mm, 6 mm, and 12 mm Drill bits
- 10 mm Open end wrench
- Scissors
- Phillips screwdriver
- Pushpin
- Utility knife

The following tools are available through the Honda Tool and Equipment Program:


- Trim Tool Set (T/N SOJATP2014)
- Plastic Trim Tool (T/N SILTRIMTL10)



# Germain Honda of College Hills

## INSTALLATION

1. Fix the tilt lever of the column in the lowest position and the telescopic in the position that is pulled most.





QL01101AB

2. Attach masking tape to protect the vehicle.

### NOTE

Do not remove the masking tape until after the parts are installed.

3. Turn the steering wheel 90° counterclockwise.



QL01102AB



4. Release the left side of the steering column upper cover.

### NOTE

Release in the order shown.

# Germain Honda of College Hills

5. Turn the steering wheel 180° clockwise.




RETAINING TAB  
QL01103AB

6. Release the right side of the steering column upper cover.

## NOTE

Release in the order shown.


7. Release the steering column upper cover.



2 RETAINING  
TABS

QL01104AB


8. Secure the steering column upper cover.  
9. Remove the self-tapping screw.



QL01105AB

# Germain Honda of College Hills




10. Turn the steering wheel 180° counterclockwise.



11. Remove the self-tapping screw.  
12. Disconnect the negative cable from the battery.


## NOTE

With the driver's door open, turn the vehicle to the OFF (LOCK) mode, then wait at least 3 minutes before disconnecting the 12 volt negative battery cable.





QCD0502BM

13. Move the shift lever to the "D" position.



14. Remove the passenger's dashboard side lid.




# Germain Honda of College Hills

15. Attach masking tape to protect the vehicle.

## NOTE


Do not remove the masking tape until after the parts are installed.



METER  
VISOR


MASKING  
TAPE

INSTRUMENT  
PANEL



METER  
VISOR

OPPOSITE SIDE VIEW



INSTRUMENT  
PANEL


MASKING  
TAPE

QM22501AB

16. Remove the center trim panel.

VEHICLE  
CONNECTORS

14 CLIPS



RETAINING  
TAB

CENTER TRIM  
PANEL

QL93002BB


17. Attach masking tape to protect the vehicle.

## NOTE

Do not remove the masking tape until after the parts are installed.

SHIFT  
LEVER

MASKING  
TAPE




QL93003AB




# Germain Honda of College Hills


18. Remove the shift lever panel.



19. Remove the console panel.



20. Remove the passenger's dashboard under cover.




# Germain Honda of College Hills

21. Remove the passenger's knee airbag.


## NOTICE

- Do not drop the removed knee airbag or hit it on an object.
- Place the removed knee airbag in a safe place with the padded surface (top) facing upward.



22. Open the glove box.


## 2 SELF-TAPPING SCREWS



23. Remove the self-tapping screws.


24. Close the glove box.

25. Remove the glove box.




# Germain Honda of College Hills

26. Release the integrated management unit.




QL93010AB

27. Remove the passenger's door sill trim.



PASSENGER'S  
DOOR SILL TRIM

3 RETAINING TABS



3 CLIPS


QL00101AB

28. Remove the passenger's kick panel.



PASSENGER'S  
KICK PANEL


DOOR  
OPENING  
SEAL



2 CLIPS


QL00102AB

29. Remove the driver's outside lower cover.



2 VEHICLE  
CLIPS

VEHICLE  
CONNECTOR



3 RETAINING  
TABS

DRIVER'S OUTSIDE  
LOWER COVER

4 CLIPS

QL00103BB




# Germain Honda of College Hills

30. Remove the driver's knee airbag.


## NOTICE

- Do not drop the removed knee airbag or hit it on an object.
- Place the removed knee airbag in a safe place with the padded surface (top) facing upward.




QL00104AB

31. Remove the steering column lower cover.



QL01109AB


32. Release the aspirator hose.



QL00105AB


# Germain Honda of College Hills

33. Remove the driver's door sill trim.



3 RETAINING TABS


DRIVER'S  
DOOR SILL TRIM




3 CLIPS

QL00106AB

34. Remove the driver's kick panel.



DOOR  
OPENING  
SEAL




DRIVER'S  
KICK PANEL

2 CLIPS

QL00107AB


35. Attach the fuse labels.



QL00401AB

# Germain Honda of College Hills


36. Secure the harness.



**HARNESS  
BRANCH  
SECTION**

**VEHICLE HARNESS  
BRANCH SECTION**

**WIRE TIE**





**VEHICLE HARNESS** QL00402AB

37. Secure the harness connector.

**HARNESS 8-PIN  
CONNECTOR**


**WIRE TIRE  
WITH HOLDER**

**FUSE BOX**



**HARNESS 8-PIN  
CONNECTOR**



**FUSE BOX**



QL00403AB


# Germain Honda of College Hills

38. Secure the fuse case.




QL00404AB

39. Plug-in the harness connector.



**WITH OTHER ACCESSORY HARNESS**  
If the dummy connector is plugged, unplug it.




QL00405AB



# Germain Honda of College Hills

40. Secure the harness.




VEHICLE CLIP  
GREEN TAPE  
2 WIRE TIES

QL00406BB



41. Secure the harness.

## NOTE


Be careful not to damage the harness.



VEHICLE BRACKET  
WIRE TIE  
HARNESS



HARNESS  
WIRE TIE





WIRE TIE  
OTHER ACCESSORY HARNESS  
WITH OTHER ACCESSORY HARNESS  
VEHICLE BRACKET

QL00407BB

# Germain Honda of College Hills



42. Route the harness.



**HARNESS**

QL00501AB


43. Route the harness.



**HARNESS**



QL00502AB

44. Secure the harness.



QL00505AB

45. Route the harness.




**HARNESS**


QL00503AB

# Germain Honda of College Hills

46. Secure the harness.



47. Secure the harness.








# Germain Honda of College Hills

48. Secure the harness.




## NOTE

Be careful not to damage the harness.



OTHER ACCESSORY HARNESS  
2 WIRE TIES  
WITH OTHER ACCESSORY HARNESS  
2 WIRE TIES  
HARNESS  
QL00507AB


49. Secure the harness.



QL00508AB


# Germain Honda of College Hills

50. Secure the harness.



VEHICLE  
HARNESS


WIRE TIE



HARNESS

VEHICLE CLIP

URETHANE  
TAPE




WIRE TIE


EDGE OF  
URETHANE  
TAPE

QL00509AB

51. Secure the harness.



HARNESS



VEHICLE  
HARNESS


2 WIRE  
TIES

VEHICLE  
CLIP


QL00510AB

# Germain Honda of College Hills

52. Secure the harness.




53. Plug-in the vehicle connector.




54. Secure the harness and connectors.

55. Cut the template.




# Germain Honda of College Hills

56. Secure the template (DR).



QL00604AB

57. Pierce the driver's kick panel.




58. Remove the template (DR).




# Germain Honda of College Hills

59. Cut the ribs.




60. Attach masking tape to protect the driver's kick panel.



61. Drill the driver's kick panel.


NOTE
Make sure to drill the correct position.




62. Remove the masking tape.

# Germain Honda of College Hills


63. Install the light.



64. Plug-in the harness connector.




**HARNESS 4-PIN  
CONNECTOR**




65. Install the driver's kick panel.

66. Secure the template (AS).




# Germain Honda of College Hills

67. Pierce the passenger's dashboard under cover.



68. Remove the template (AS).

69. Cut the rib.





# Germain Honda of College Hills


70. Drill the passenger's dashboard under cover.

## NOTE


Make sure to drill the correct position.



3 mm →  
5 mm DRILL BITS




MARK



PASSENGER'S  
DASHBOARD  
UNDER COVER  
(outside)

MARK




3 mm → 6 mm →  
8 mm → 12 mm  
DRILL BITS



QL00614BB

71. Install the light.






QL00616AB

# Germain Honda of College Hills

- 72. Install the glove box.
- 73. Install the passenger's knee airbag.

## NOTE

Make sure to replace with the washer-bolts included in this kit.




QL00618AB





5.1-11 lb-ft  
(6.9-14.4 N·m)

- 74. Plug-in the harness connector.



QL00619AB

- 75. Install the passenger's dashboard under cover.
- 76. Install the console panel.



QL00620AB

- 77. Plug-in the harness connector.
- 78. Install the shift lever panel.

# Germain Honda of College Hills

79. Check that all parts are installed and properly routed.

## NOTE

- Check that all harnesses are not pulled or pinched.
- Make sure all clips and wire ties are securely installed.


80. Install all removed parts except for the self-tapping screws removed in steps 9 and 11 and steering column upper cover.

### <Installing the Driver's Knee Airbag>

81. Install the driver's knee airbag.



## NOTE

Make sure to replace with the washer-bolts included in this kit.



VEHICLE  
CONNECTOR

AIRBAG




DRIVER'S  
KNEE AIRBAG

2 WASHER-BOLTS  
(supplied) QL00621AB



5.1-11 lb-ft  
(6.9-14.4 N·m)

82. Connect the negative cable to the battery.



Q060702BM

83. Install the self-tapping screws removed in steps 9 and 11 and steering column upper cover.

84. Turn the engine switch (power switch) to ON; the SRS indicator should come on for about 6 seconds and then go off.

85. Check that the ambient lights turn on when opening the door.

86. When the light switch is in the "AUTO" position, while the parking lights and the headlights are on, the ambient lights should be on.

87. Check that the interior illumination brightness varies along with the instrument panel brightness by turning the brightness control knob.

88. Make sure all accessories and systems operate properly.

89. If necessary, restore the systems back to normal operation as described in the service information.

90. Press and hold the audio unit power button for 2 seconds to restore the audio and navi (if equipped) system functions.