

Germain Honda of College Hills



INSTALLATION INSTRUCTIONS


Accessory
DOOR EDGE FILMS

Application
**2023 PILOT
MODEL SERIES**

Publications No.
VERSION 1
Issue Date
NOV 2022

GENERAL VIEW

If you are also installing body side moldings (sold separately), install them before you install the door edge films.



QM51001AA

FOR YOUR SAFETY (Read carefully.)

Warning Symbols

Safety: Your safety, and the safety of others, is important. To help you make informed decisions about service procedures, we have provided safety messages where appropriate. Of course, it is not practical or possible to warn you about all the hazards associated with servicing a vehicle - you must use your own good judgment.

You will find important safety messages preceded by one of the following symbols:

*All symbols are not used in all installation instructions.



DANGER

You will be killed or seriously hurt if you do not follow the instructions.



WARNING

You can be killed or seriously hurt if you do not follow the instructions.



CAUTION

You can be hurt if you do not follow the instructions.

NOTICE

Gives advice to prevent damage to the product, vehicle, the environment or other property.

NOTE

Gives helpful information or instructions to be followed when installing this product.



Indicates a prohibited action.

Germain Honda of College Hills

Procedure and Location Icons

These icons indicate the work location and the worker's point of view.

*All icons are not used in all installation instructions.



The location on the vehicle.



The location in the vehicle.
(Instrument panel.)



Wear eye protection.



Wear heavy gloves.



Use an assistant.



Place the part on a blanket.



Work perpendicular.



Remove any burrs.



Use touch-up paint and allow to dry.



Tighten to the specified torque.



Apply firm pressure while rolling, especially at the ends, to set the adhesive.



Press firmly.



Clean with isopropyl alcohol.



Return the original part to the customer.
(Do not reuse.)

Safety: General

- Be careful not to damage the vehicle or the parts.
- The illustrations may differ slightly from the actual accessory.

Safety: Accessory

- Do not install the accessory on a dirty surface or in direct sunlight.
- Make sure the ambient air temperature is 60°F (15°C) or above when installing accessories that use a bonding material.
- When applying adhesive material, make sure it is lined up properly before attaching. Once the adhesive material touches the surface, do not try to remove it. If you do, you could damage the part before the adhesive releases.
- Cover nearby parts with a shop towel to prevent getting them wet.
- Always wear gloves when working with 3M protective tape application solution.
- Use the 3M protective tape application solution with a spray bottle.
- Do not wash the vehicle for 24 hours to allow the adhesive to cure.

Germain Honda of College Hills








PARTS LIST

Door Edge Films Kit

(P/N 08P20-T90-100)

(P/N 08P20-T90-P00)

(*: The part differs depending on the kit.)

Left front door edge film (identification mark: FR-L)	Right front door edge film (identification mark: FR-R)	Left rear door edge film (identification mark: RR-L)	Right rear door edge film (identification mark: RR-R)
			
*Alcohol wipes (4) (P/N 08P20-T90-100)	*Applicator (P/N 08P20-T90-100)	*Felt sleeve (P/N 08P20-T90-100)	
			

REQUIRED TOOLS AND SUPPLIES

- Shop towel
- 3M Protective tape application solution
- Gloves
- Scissors


Germain Honda of College Hills

INSTALLATION

1. Clean the attaching area.


NOTE

Allow to dry thoroughly.



LEFT FRONT DOOR
(outside)



LEFT FRONT DOOR
(inside)



2. Spray the left front door.

NOTE

Spray the outer surface of the door only.



LEFT FRONT
DOOR

3M PROTECTIVE TAPE
APPLICATION SOLUTION



QM51003AA

Germain Honda of College Hills

3. Attach the left front door edge film.

NOTE

Make sure to check the identification mark before installation.




QM51004AA

4. Secure the left front door edge film.


NOTE

- Move the felt sleeve in one direction only.
- Make sure that there are no air bubbles.



QM51007AA

5. Remove the protective film.




QM51008AA

Germain Honda of College Hills

6. Secure the left front door edge film.

NOTE


- Do not trim or damage the seam sealant.
- Make sure to prevent air from entering.



LEFT
FRONT DOOR
EDGE FILM

LEFT
FRONT DOOR

LEFT
FRONT DOOR
(inside)



SEAM
SEALANT

SECTION VIEW



LEFT FRONT
DOOR EDGE
FILM

QM51101AA

7. Wipe off the 3M protective tape application solution.

NOTE

Allow to dry thoroughly.



SHOP TOWEL


LEFT FRONT DOOR
(outside)

QM51102AA

8. Clean the attaching area.


NOTE

Allow to dry thoroughly.



LEFT REAR DOOR
(outside)

LEFT REAR DOOR
(inside)



ALCOHOL
WIPE


QM51103AA

Germain Honda of College Hills

9. Spray the left rear door.

NOTE

Spray the outer surface of the door only.



LEFT REAR DOOR (outside)

QM51104AA

10. Choose one of these options.

- With fender flares

Go to step 11

- Without fender flares

Go to step 12

11. Cut the left rear door edge film.

NOTE

Make sure to check the identification mark before installation.

LEFT REAR DOOR EDGE FILM (identification mark: RR-L)

MARKING LINE (Cut.)




Do not use.

QM51105BA

12. Attach the left rear door edge film.

NOTE

Make sure to check the identification mark before installation.




QM51106AA

Germain Honda of College Hills

13. Secure the left rear door edge film.


NOTE

- Move the felt sleeve in one direction only.
- Make sure that there are no air bubbles.



QM51107AA

14. Remove the protective film.




QM51108AA


15. Secure the left rear door edge film.

NOTE


- Do not trim or damage the seam sealant.
- Make sure to prevent air from entering.



LEFT REAR DOOR
EDGE FILM LEFT REAR DOOR LEFT REAR DOOR
EDGE FILM



SECTION VIEW





LEFT REAR DOOR
(inside)

QM51109BA

Germain Honda of College Hills

16. Wipe off the 3M protective tape application solution.

NOTE
Allow to dry thoroughly.




SHOP TOWEL

LEFT REAR DOOR
(outside)

QM51110AA

17. Repeat the same procedures on the other side.



Q9D1014AM

18. Check that all parts are installed properly.