

# Germain Honda of College Hills




## INSTALLATION INSTRUCTIONS

Accessory  
**DOOR SILL  
PROTECTION FILMS**

Application  
**2023 PILOT  
MODEL SERIES**

Publications No.  
**VERSION 1**  
Issue Date  
**NOV 2022**

## GENERAL VIEW



QM42701AG

## FOR YOUR SAFETY (Read carefully.)

### Warning Symbols

**Safety:** Your safety, and the safety of others, is important. To help you make informed decisions about service procedures, we have provided safety messages where appropriate. Of course, it is not practical or possible to warn you about all the hazards associated with servicing a vehicle - you must use your own good judgment.

You will find important safety messages preceded by one of the following symbols:

\*All symbols are not used in all installation instructions.

**⚠ DANGER**

You will be killed or seriously hurt if you do not follow the instructions.

**⚠ WARNING**

You can be killed or seriously hurt if you do not follow the instructions.

**⚠ CAUTION**

You can be hurt if you do not follow the instructions.

**NOTICE**

Gives advice to prevent damage to the product, vehicle, the environment or other property.

**NOTE**

Gives helpful information or instructions to be followed when installing this product.




Indicates a prohibited action.

# Germain Honda of College Hills


## Procedure and Location Icons

These icons indicate the work location and the worker's point of view.

\*All icons are not used in all installation instructions.



The location on the vehicle.



The location in the vehicle.  
(Instrument panel.)



Wear eye protection.



Wear heavy gloves.



Use an assistant.



Place the part on a blanket.



Work perpendicular.



Remove any burrs.



Use touch-up paint and allow to dry.



Tighten to the specified torque.



Apply firm pressure while rolling, especially at the ends, to set the adhesive.



Press firmly.



Clean with isopropyl alcohol.



Return the original part to the customer.  
(Do not reuse.)

## Safety: General

- Be careful not to damage the vehicle or the parts.
- The illustrations may differ slightly from the actual accessory.

## Safety: Accessory

- Do not install the accessory on a dirty surface or in direct sunlight.
- Make sure the ambient air temperature is 60°F (15°C) or above when installing accessories that use adhesive material.
- When applying adhesive material, make sure it is lined up properly before attaching. Once the adhesive material touches the surface, do not try to remove it. If you do, you could damage the part.
- Cover nearby parts with a shop towel to prevent getting them wet.
- Always wear gloves when working with 3M protective tape application solution.
- Use 3M protective tape application solution with a spray bottle.
- Do not wash the vehicle for 24 hours to allow the adhesive to cure.

# Germain Honda of College Hills








## PARTS LIST

### Door Sill Protection Films Kit

(P/N 08P04-T90-100)

(P/N 08P04-T90-P00)

(\*: The part differs depending on the kit.)

Left front protection film (identification mark: FR-L)	Right front protection film (identification mark: FR-R)	Left rear protection film (identification mark: RR-L)	Right rear protection film (identification mark: RR-R)
			
*Alcohol wipes (4) (P/N 08P04-T90-100)	*Applicator (P/N 08P04-T90-100)	*Felt sleeve (P/N 08P04-T90-100)	
			



## REQUIRED TOOLS AND SUPPLIES

- Shop towel
- Masking tape
- Ruler
- Felt-tip pen
- Gloves
- 3M Protective tape application solution

# Germain Honda of College Hills

## INSTALLATION

1. Open the left front door.




QM42702AG

2. Attach masking tape.

3. Attach masking tape.

### NOTE

Make sure to check the identification mark before installation.



QM90601AG


4. Mark the masking tape.

# Germain Honda of College Hills

5. Clean the attaching area.

## NOTE


Allow to dry thoroughly.



**ALCOHOL  
WIPE**

QM42709BG


6. Spray the vehicle panel.



**3M PROTECTIVE TAPE  
APPLICATION SOLUTION**


QM42710BG

7. Remove the adhesive backing.



QM42711BG


8. Spray the left front protection film.



QM42712BG

# Germain Honda of College Hills

9. Line up the left front protection film.



QM42713BG




10. Secure the left front protection film.

## NOTE

Move the felt sleeve in one direction only.

APPLICATOR

FELT SLEEVE



Work from the center to the outside.


QM42714BG

# Germain Honda of College Hills


11. Secure the left front protection film.

## NOTE

Move the felt sleeve in one direction only.



Work from the inside to the outside.



SECTION VIEW


Work from the inside to the outside.

QM42715BG


12. Secure the left front protection film.

## NOTE

Move the felt sleeve in one direction only.



Work from the center to the outside.



SECTION VIEW



QM42801BG

# Germain Honda of College Hills

13. Remove the masking tape.

## NOTE

Carefully remove the masking tape from the top of the protection film and the vehicle panel. Make sure not to pull the part away from the vehicle panel.



Peel along the left front protection film.


Do not pull up.

QM42802BG

14. Wipe off the 3M protective tape application solution.

## NOTE

Allow to dry thoroughly.





SHOP TOWEL

QM42803AG

# Germain Honda of College Hills

15. Open the left rear door.




QM42804AG

16. Attach masking tape.

17. Attach masking tape.

## NOTE

Make sure to check the identification mark before installation.




QM90602AG

18. Mark the masking tape.

# Germain Honda of College Hills

19. Clean the attaching area.


<b>NOTE</b>
Allow to dry thoroughly.



ALCOHOL WIPE

QM42811BG


20. Spray the vehicle panel.



3M PROTECTIVE TAPE  
APPLICATION SOLUTION


QM42812BG

21. Remove the adhesive backing.



QM42813BG


22. Spray the left rear protection film.



QM42814BG

# Germain Honda of College Hills

23. Line up the left rear protection film.




QM42815BG

24. Secure the left rear protection film.

## NOTE

Move the felt sleeve in one direction only.




QM42816BG

# Germain Honda of College Hills


25. Secure the left rear protection film.

## NOTE

Move the felt sleeve in one direction only.



Work from the inside to the outside.



SECTION VIEW


Work from the inside to the outside.

QM42817BG


26. Secure the left rear protection film.

## NOTE

Move the felt sleeve in one direction only.



Work from the center to the outside.



SECTION VIEW



QM42818BG

# Germain Honda of College Hills

27. Remove the masking tape.

## NOTE

Carefully remove the masking tape from the top of the protection film and the vehicle panel. Make sure not to pull the part away from the vehicle panel.



Peel along the left rear protection film.


Do not pull up.

QM42819BG

28. Wipe off the 3M protective tape application solution.

## NOTE


Allow to dry thoroughly.



SHOP TOWEL

QM42820AG

29. Repeat the same procedures on the other side.



Repeat steps 1 through 28.

Q9D1014AM

30. Check that all parts are installed properly.