



**INSTALLATION
INSTRUCTIONS**

Accessory

SHIFT KNOB
P/N 54102-XTK-000

Application

2010 FIT MUGEN

Publications No.


All 42201

Issue Date

JULY 2009

PARTS LIST

Shift Knob




Nut




INSTALLATION

1. Remove the shift knob by rotating it counterclockwise. Set the knob aside; it will not be reused.

SHIFT KNOB
(Set Aside.)



2. Thread the nut all the way onto the shift shaft lever. Install the new shift knob by turning it clockwise until it almost touches the nut. Turn the knob until the orientation of the shift pattern is correct, then tighten the nut against the shift knob.



USE AND CARE

- Use a sponge or cloth and a solution of mild liquid dishwashing soap and water to clean the shift knob.
- Rinse the knob completely with water, then dry it with a shop towel.
- Never use organic solvents such as benzene, thinner, or gasoline to clean the shift knob.