<u>www.collegehillshonda.com</u>

INSTALLATION INSTRUCTIONS

SECOND ROW SEAT COVERS (without center second row seat) P/N 08P32-THR-100A Application

VERSION 1

Issue Date
JUL 2020


Publications No.

PARTS LIST

Second row seat covers



Illustration of the Second Row Seat Covers in the Vehicle




INSTALLATION

NOTE:


- Do not damage the vehicle during installation.
- Do not install the seat covers on the front seats.
 Covering the front seat may prevent the side airbag from inflating during a side impact.
- Identify each seat cover by the tags on the back.

Installing the Second Row Seat Covers

1. While pressing the head restraint guide button, remove the head restraint from the right second row seat by pulling it upward.




Fit the head restraint cover onto the head restraint.




www.collegehillshonda.com


3. Fold the right second row seat-back half way down. Fit the right second row seat cushion cover onto the right second row seat cushion.




4. Secure the right second row seat cushion cover to the right second row seat cushion with four tabs and two fasteners.



5. Secure the right second row seat cushion cover to the right second row seat cushion with one fastener.




 Fit the right second row seat-back cover onto the right second row seat-back through the seat belt. Insert the right second row seat-back cover under each head restraint guide.



www.collegehillshonda.com

7. Secure the right second row seat-back cover with two fasteners.



- 8. Raise the right second row seat-back.
- 9. Repeat steps 1 through 8 on the left side of the vehicle.
- 10. Install the head restraints on the second row seats.