



## ■ Sub-Procedure

### ● Removal

1. Turn the vehicle to the ON mode.
2. Turn the vehicle to the OFF mode, then turn and hold the wiper/washer switch to the MIST position within about 10 seconds.
3. Release the wiper/washer switch.  
NOTE: The wiper arm stops at the service position.
4. Lift the wiper arm (a) off the windshield.
5. Remove the wiper blade assembly (b).