



INSTALLATION INSTRUCTIONS

Accessory
REAR SEAT-BACK PROTECTOR
 P/N 08U43-T5A-100

Application
2018 FIT

Publications No.
VERSION 1
 Issue Date
JUL 2017

PARTS LIST

Left seat-back protector



Right seat-back protector




Left cargo floor protector



Right cargo floor protector




Illustration of the Rear Seat-back Protector Installed in the Vehicle




INSTALLATION

Installing the Protectors


1. Remove each head restraint by pushing the button and lifting up on the head restraint, then install the three loops on the left and right seat-back protectors through the headrests as shown.



2. Fold down the rear seat-backs. Position the left and right seat-back protectors on the rear seat-backs. Secure the left and right seat-back protectors to the rear seat-backs with the 10 fasteners.



- Position the left and right cargo floor protectors on the cargo area floor lid. Secure the left and right cargo floor protectors to the cargo area floor lid with the 10 fasteners, and insert them between the seat-back protectors and rear seat-backs as shown.



- Check the protectors by moving the rear seat-backs back and forth.
NOTE: Adjust the position of the protectors if necessary.

