



INSTALLATION INSTRUCTIONS

Accessory
REAR SEAT-BACK PROTECTORS
P/N 08U43-T7S-100

Application
2022 HR-V

Publications No.
VERSION 1
Issue Date
JUL 2021

PARTS LIST


Left seat-back protector



Right seat-back protector




Left cargo floor protector



Right cargo floor protector




Illustration of the Rear Seat-back Protectors Installed in the Vehicle




INSTALLATION

Installing the Seat-Back Protectors


1. While pressing on each head restraints guide button, lift up the three head restraints by pulling them upward. Install the three loops on the left and right seat-back protectors through the head restraints as shown. Install each head restraints to the left and right rear seat-backs.



2. Fold down the left and right rear seat-backs, and peel back the cargo floor lid. Line up the left and right seat-back protectors with the tether anchor covers on the left and right rear seat-backs as shown. Secure the left and right seat-back protectors to the left and right rear seat-backs with the 28 fasteners.



- Position the left and right cargo floor protectors on the cargo floor lid. Secure the left and right cargo floor protectors to the cargo floor lid with the 19 fasteners, and put them on the left and right seat-back protectors as shown.



- Check the protectors by moving the left and right rear seat-backs back and forth.
NOTE: Adjust the position of the protectors if necessary.

