



## HONDA INSTALLATION INSTRUCTIONS

### Accessory

2ND ROW SEAT COVERS  
P/N 08P32-T7S-100

### Application

2022 HR-V

### Publications No.

VERSION 1

### Issue Date

JUL 2021

## PARTS LIST

2 Head restraint covers




Center head restraint cover

Left seat-back cover

Right seat-back cover

Left seat cushion cover


Right seat cushion cover



## INSTALLATION


### Installing the Head Restraint Covers

1. Remove each head restraint by pushing on the button and lifting up on the head restraint.




QC91301AK

2. Install a head restraint cover on each head restraint as shown.




## Installing the Left Seat-back Cover


3. Pull the lever and fold the left seat-back halfway forward. Install the left seat-back cover over the left seat-back.



4. Lift up the left seat cushion. Secure the fastener on the left seat-back cover as shown.




5. Lower the left seat cushion and fold the left seat-back fully forward. Pull the seat-back cover tight and secure it to the left seat-back with five fasteners.



QC91304BK


6. Lift the left seat-back. Tuck the left seat-back cover under each head restraint guide as shown.



QDN1703AT


## Installing the Left Seat Cushion Cover

7. Install the left seat cushion cover over the left seat cushion.




QDN1704BT

8. Lift up the left seat cushion. Secure the fasteners on the left seat cushion cover as shown.




QDN1705BT

9. Secure the left seat cushion cover to the left seat cushion with the two hooks and two loops, and lower the left seat cushion.




## Installing the Right Seat-back Cover


10. Pull the lever and fold the right seat-back halfway forward. Install the right seat-back cover over the right seat-back.




11. Lift up the right seat cushion. Secure the fastener on the right seat-back cover as shown.



12. Lower the right seat cushion, and fold the right seat-back fully forward. Pull the seat-back cover tight, and secure it to the right seat-back with four fasteners.




13. Lift the right seat-back.



QDN1709AT


## Installing the Right Seat Cushion Cover

14. Install the right seat cushion cover over the right seat cushion.





QDN1710BT

15. Lift up the right seat cushion.



QDN1711BT

16. Secure the right seat cushion cover to the right seat cushion with the two hooks and two loops, and lower the right seat cushion.



QDN1712AT

17. Install the head restraints on seat-backs.