



INSTALLATION INSTRUCTIONS

Accessory
ALL-SEASON FLOOR MATS
 P/N 08P17-TGS-100

Application
2019 PASSPORT

Publications No.
VERSION 1


Issue Date
JAN 2019

PARTS LIST

Driver's all-season floor mat



Passenger's all-season floor mat



Rear all-season floor mat





Illustration of the All-Season Floor Mats in the Vehicle




INSTALLATION

NOTE:


- Before installing the mats, identify their installation positions.
- Connect the mats to the anchors to prevent the mats from sliding forward and possibly interfering with the pedals.
- If you remove a mat, make sure you re-anchor it when you put it back in your vehicle.
- If you replace a mat, use a factory mat designed to be used with the anchors.
- If you use a non-factory mat in the driver's footwell, make sure it fits properly and that it can be used with the anchors.
- Do not put an additional mat on top of the anchored mat. An additional mat may slide forward and possibly interfere with the pedals.
- Position the rear seat floor mat properly. If it is not properly positioned, the floor mat can interfere with the front seat functions.

Installing the All-Season Floor Mats

1. If equipped, remove the standard floor mats as described in the vehicle owner's manual.
2. Place the grommets in the driver's all-season floor mat over the anchors. Push the grommets into the anchors to secure the retaining tabs, then turn the knobs 90° to secure the driver's all-season floor mat.



3. Place the grommets in the passenger's all-season floor mat over the anchors. Push the grommets into the anchors to secure the retaining tabs, then turn the knobs 90° to secure the passenger's all-season floor mat.



4. Place the grommets in the rear all-season floor mat over the anchors. Push the grommets into the anchors to secure the retaining tabs, then turn the knobs 90° to secure the rear all-season floor mat.

