
 HONDA INSTALLATION INSTRUCTIONS	Accessory	Application	Publications No.
	SURFBOARD ATTACHMENT P/N 08L05-TA1-100	2010 ODYSSEY	All 41833
			Issue Date JUNE 2009
Put this information in the glove box with the vehicle owner's manual.			

PARTS LIST

4 Bases




8 Knobs




8 Bolts



2 Attachment Straps




4 Metal brackets




INSTALLATION

NOTE: Be careful not to damage the body paint finish.

1. Loosely install a bolt and knob onto one of the bases as shown.



2. Position the base on the crossbar. Loosely install a bolt and knob as shown.




3. Repeat steps 1 and 2 for the three remaining bases.

- Center the surfboard upside down on the roof of the vehicle with the tail toward the front of the vehicle.


NOTE: When mounting two boards, place the second board on top of the first.

- Adjust the position of the bases so that the




bottom of the surfboard rests on the rubber part of the bases. Tighten all knobs firmly and evenly.

NOTE: The crossbars must be at least 24 in. (610 mm) apart for safe use.




- Slide the buckle on the attachment strap into the clip on the base.

NOTE: For proper alignment, the buckle must be fully inserted into the clip as shown.




- Rotate the buckle up to lock it into the base. Repeat this step at the remaining bases.




8. Pull the end of the attachment straps to secure the surfboard to the carrier. Make certain all mounting hardware is secure, then tighten as necessary.

NOTE: Be careful not to overtighten the attachment straps as you could damage the surfboard.



Surfboard Removal

1. Open the latches to loosen the attachment straps.



2. Rotate the buckles down to unlock the attachment straps and slide the buckles out of the bases.

