



## HONDA INSTALLATION INSTRUCTIONS

### Accessory

2ND ROW SEAT COVERS  
P/N 08P32-T5A-101

### Application

2019 FIT

### Publications No.

VERSION 1

### Issue Date

APR 2018

## PARTS LIST

2 Head restraint covers

Center head restraint cover

Left seat-back cover

Right seat-back cover

Left seat cushion cover


Right seat cushion cover




## INSTALLATION

### Installing the Head Restraint Covers

1. Remove each head restraint by pushing on the button and lifting up on the head restraint.




2. Install a head restraint cover on each head restraint as shown.




## Installing the Left Seat-back Cover


3. Pull the lever and fold the left seat-back halfway forward. Install the left seat-back cover over the left seat-back.



4. Lift up the left seat cushion. Secure the fastener on the left seat-back cover as shown.




5. Lower the left seat cushion, and fold the left seat-back fully forward. Pull the seat-back cover tight, and secure it to the left seat-back with five fasteners.



QC91304BK


6. Lift the left seat-back. Tuck the left seat-back cover under each head restraint guide as shown. NOTE: Make sure that the lower anchor holes are not hidden by the cover.



QG10701BT


## Installing the Left Seat Cushion Cover

7. Release two seat belt buckles from two loops.




QC91306AK

8. Install the left seat cushion cover over the left seat cushion.




QC91307BK


9. Install the two seat belt buckles into the loops.



10. Lift up the left seat cushion. Secure the fasteners on the left seat cushion cover as shown.




11. Secure the left seat cushion cover to the left seat cushion with the two hooks and two loops, and lower the left seat cushion.




## Installing the Right Seat-back Cover


12. Pull the lever and fold the right seat-back halfway forward. Install the right seat-back cover over the right seat-back.




13. Lift up the right seat cushion. Secure the fastener on the right seat-back cover as shown.



14. Lower the right seat cushion, and fold the right seat-back fully forward. Pull the seat-back cover tight, and secure it to the right seat-back with four fasteners.




15. Lift the right seat-back. Tuck the right seat-back cover under each head restraint guide as shown. NOTE: Make sure that the lower anchor holes are not hidden by the cover.




## Installing the Right Seat Cushion Cover


16. Release the two seat belt buckles from the loops.




17. Install the right seat cushion cover over the right seat cushion.




18. Install the two seat belt buckles into the loops.



19. Lift up the right seat cushion. Secure the fasteners on the right seat cushion cover as shown.



20. Secure the right seat cushion cover to the right seat cushion with two hooks and two loops, and lower the right seat cushion.



21. Install the head restraints on the seat-backs.