



**INSTALLATION
INSTRUCTIONS**

Accessory
CROSSBARS
P/N 08L04-SZA-100


Application
2010 PILOT

Publications No.
All 41637-43274

Issue Date
JAN 2010

PARTS LIST

2 Crossbars



2 Torx bolts




TOOLS AND SUPPLIES REQUIRED

Flat-tip screwdriver

Shop towel

T-30 Torx driver

Illustration of the Crossbars Installed on the Vehicle



INSTALLATION



Customer Information: The information in this installation instruction is intended for use only by skilled technicians who have the proper tools, equipment, and training to correctly and safely add equipment to your vehicle. These procedures should not be attempted by “do-it-yourselfers.”

NOTE:

- The weight of cargo must not exceed the maximum weight capacity of 75 kg (165 lbs).
- Wipe and clean the roof rails before installing the crossbars.
- Be extremely careful not to damage the roof and other finished surfaces of the body when installing the crossbars.


Installing the Crossbars

1. Remove the rear roof rail covers from the roof rails by disengaging two clips each.




2. Slide the crossbars into the roof rails with the adjustment screws on the passenger's side of the vehicle, and align the mark on the crossbars with the mark on the roof rails as shown. Make sure the crossbars are inserted in the correct position and direction.

NOTE: If the crossbars are installed incorrectly excessive wind noise will occur.




The crossbars are directional, with distinct left-side and right-side mounts.




The slots that fit in the rails are shaped differently on the right and left side.

3. Tighten eight thumbwheel screws to secure the crossbars to the roof rails.



4. Install two Torx bolts to the roof rails securely.



5. Reinstall the roof rail covers. Make sure they are securely snapped into place.

USE AND CARE

- Check the roof rails and crossbar mounting bolts frequently, and re-tighten if necessary.
- Distribute the weight of the cargo evenly, and do not exceed the maximum weight capacity of 75 kg (165 lbs).