



INSTALLATION INSTRUCTIONS

Accessory
ROOF RAILS
 P/N 08L02-T6Z-101
 P/N 08L02-T6Z-101A

Application
2017 RIDGELINE

Publications No.
VERSION 1
 Issue Date
MAY 2016

PARTS LIST

Left roof rail



Left front roof rail cover



Left rear roof rail cover



Right roof rail



Right front roof rail cover



Right rear roof rail cover



8 TORX nuts




4 TORX screws



6 Molding clips



2 Roof molding cover clips



TOOLS AND SUPPLIES REQUIRED

Ratchet

Masking tape

Torque wrench

Ruler

Tape measure

Felt-tip pen

File


T-20 and T-40 TORX bits

Eye protection (face shield, safety goggles, etc.)

The following tools are available through the Honda Tool and Equipment Program. On the iN, click on: Service > Service Bay > Tool and Equipment Program, then enter the number under "Search." Or, call 888-424-6857.

- Plastic Trim Tool (T/N SILTRIMTL10)
- Air Saw (T/N AT192A)

Illustration of the Roof Rails on the Vehicle




QE02104BN

INSTALLATION


Customer Information: The information in this installation instruction is intended for use only by skilled technicians who have the proper tools, equipment, and training to correctly and safely add equipment to your vehicle. These procedures should not be attempted by "do-it-yourselfers."

NOTE: Be extremely careful not to damage the roof and other finished surfaces of the body when installing the roof rails.


1. Attach a piece of masking tape on the vehicle panel and one on the left roof molding in the center. Using a felt-tip pen, draw a line in the center on each masking tape so they are in a straight line.




2. Using a plastic trim tool, carefully remove the left roof molding.




3. Remove the three molding clips from either the left roof molding or the roof stud bolts.




4. Remove any excess sealant from the four roof stud bolts.




5. Remove the left roof molding cover from the left roof molding.




6. Using a felt-tip pen, mark the left roof molding as shown.



7. While wearing eye protection, use an air saw to cut the left roof molding at the two marks made in step 6. Remove any burrs.




8. Install the three new molding clips to the left roof molding.




9. Remove the roof molding cover clip and install the new roof molding cover clip into the left roof molding cover as shown.


NOTE: Make sure to install the new roof molding cover clip in the correct orientation.




10. Install the left roof molding cover and left roof molding with the three molding clips and one roof molding cover clip. Align the marks made in step 1 on the vehicle panel and left roof molding.




11. Install the left roof rail with the four TORX nuts. Torque the TORX nuts to 18.6-24.5 N·m (14-18 lb·ft).



12. Install the left front roof rail cover to the left roof rail with the two clips and one TORX screw. Torque the TORX screw to 2.9-4.9 N·m (2.1-3.6 lb·ft).



13. Install the left rear roof rail cover to the left roof rail with the two clips and one TORX screw. Torque the TORX screw to 2.9-4.9 N·m (2.1-3.6 lb·ft).



14. Remove the masking tape from the vehicle.
15. Repeat steps 1 through 14 on the right side of the vehicle to install the right roof rail.