



HONDA INSTALLATION INSTRUCTIONS

Accessory

SPLASH GUARDS
P/N 08P00-T2F-100A

Application

2017 ACCORD
4-DOOR

Publications No.

VERSION 1

Issue Date

JUN 2016

PARTS LIST

Left front splash guard



Right front splash guard



Left rear splash guard



Right rear splash guard



8 Washer-screws



2 Spring nuts



2 Clips A



2 Clips B



TOOL AND SUPPLIES REQUIRED

Felt-tip pen

Tape

Eye protection (face shield, safety goggles, etc.)

Phillips screwdriver

Pushpin

Stubby Phillips screwdriver

Utility knife

Ruler

Drill


3 mm, 6 mm, 8 mm, and 10 mm Drill bits

File

The following tool is available through the Honda Tool and Equipment Program. On the iN, click on: Service > Service Bay > Tool and Equipment Program, then enter the number under "Search". Or, call 888-424-6857.

- Trim Tool Set (T/N SOJATP2014)
- Plastic Trim Tool (T/N SILTRIMTL10)

Illustration of the Splash Guards on the Vehicle



QE20901AC

INSTALLATION


Customer Information: The information in this installation instruction is intended for use only by skilled technicians who have the proper tools, equipment, and training to correctly and safely add equipment to your vehicle. These procedures should not be attempted by "do-it-yourselfers."

NOTE:

- Do not damage the paint finish.
- Clean and wax the areas to be covered using a high-quality paste wax.


Installing the Front Splash Guards

1. Raise the vehicle off the ground and support it as shown in the service manual.
2. Turn the steering wheel fully counterclockwise.




3. Remove and discard the clip from the left side sill trim.


4. Install one clip A into the left side sill trim.




5. Using the pushpin, pierce the center of one clip in the left front inner fender and one clip A in the left side sill trim.




6. Loosely secure the left front splash guard to the left front inner fender and left side sill trim with two washer-screws.



7. Using a felt-tip pen, mark the left side sill trim through the center of the hole in the left front splash guard. Remove the left front splash guard.




8. Using a pushpin, pierce the center of the mark made in step 7 on the left side sill trim.




QE21001AC

9. While wearing eye protection, drill the pierced mark.
NOTE: Make sure to drill perpendicular to the left side sill trim.
- To avoid drilling into the left front fender, wrap tape around each drill bit 10 mm from the tip.
 - First, drill with a 3 mm drill bit, followed by a 6 mm drill bit, then drill with an 8 mm drill bit, followed by a 10 mm drill bit. Remove any burrs.



QE21002AC


10. Install the left front splash guard to the left front inner fender with two washer-screws and one clip B, in this order 1 → 2 → 3. If necessary, trim the under sealant. Make sure there is no gap between the left front splash guard and the vehicle body. If there is a gap, loosen the three screws, hold the splash guard against the body, and tighten the three screws.




11. Turn the steering wheel fully clockwise, and repeat steps 3 through 10 to install the right front splash guard.

Installing the Rear Splash Guards


12. Remove and discard the screw from the rear bumper.



13. Remove the screw and clip from the left rear inner fender and rear bumper.
14. Using a pushpin, pierce the rear bumper at the dimple.




15. Pull away the rear bumper. Cut the left rear inner fender in the area shown.




QE21006BC

16. Install the rear bumper back into its original position.
 17. Install the clip removed in step 13.
 18. Install one spring nut over the hole in the rear bumper. Install the spring nut in the direction shown.



QE21007AC

19. Install the left rear splash guard to the rear bumper with two washer-screws and one screw removed in step 13. Install them in this order 1 → 2 → 3. Make sure there is no gap between the left rear splash guard and the vehicle body. If there is a gap, loosen the three screws, hold the splash guard against the body, and tighten the three screws.



20. Repeat steps 12 through 19 to install the right rear splash guard.