
#### HONDA

### **INSTALLATION INSTRUCTIONS**

JAN. 2025

SCUFF PLATE	2026 PASSPORT MODEL SERIES	Publications No. VERSION 1
-------------	-------------------------------	-------------------------------

#### **GENERAL VIEW**



QP70101AD



### FOR YOUR SAFETY (Read carefully.)

#### Warning Symbols

Safety: Your safety, and the safety of others, is important. To help you make informed decisions about service procedures, we have provided safety messages where appropriate. Of course, it is not practical or possible to warn you about all the hazards associated with servicing a vehicle - you must use your own good judgment.

You will find important safety messages preceded by one of the following symbols:

\*All symbols are not used in all installation instructions.

#### **A** DANGER

You will be killed or seriously hurt if you do not follow the instructions.

#### **▲** WARNING

You can be killed or seriously hurt if you do not follow the instructions.

#### **CAUTION**

You can be hurt if you do not follow the instructions.

#### MOTICE

Gives advice to prevent damage to the product, vehicle, the environment or other property.

#### ■ NOTE

Gives helpful information or instructions to be followed when installing this product.




Indicates a prohibited action.

#### Procedure and Location Icons

These icons indicate the work location and the worker's point of view.

\*All icons are not used in all installation instructions.



The location on the vehicle.



The location in the vehicle. (Instrument panel.)

	Wear eye protection.		Wear heavy gloves.
<b>K</b> —X	Use an assistant.		Place the part on a blanket.
<b>4</b> 90°	Work perpendicular.	***	Remove any burrs.
ĪĪ	Use touch-up paint and allow to dry.	lb-ft	Tighten to the specified torque.
), or	Apply firm pressure while rolling, especially at the ends, to set the adhesive.	4>	Press firmly.
	Clean with isopropyl alcohol.		Return the original part to the customer. (Do not reuse.)

#### Safety: General

- Observe all safety notes and precautions described in the service information, in addition to those described in this Installation Instruction. Be extremely careful for your safety and safety of others.
- · Always use the parts and tools specified in the installation instructions.
- Be careful not to damage the vehicle or the parts.
- · The illustrations may differ slightly from the actual accessory.

### **PARTS LIST**

### Scuff Plate Kit (P/N 08P46-3BM-100) (P/N 08P46-3BM-P00)

Parts	Parts name	QTY	Remarks
	Scuff pate	1	
	Bolt	4	
	Rivet nut	4	
	Washer	4	
	Shoulder bolt	3	

### **REQUIRED TOOLS AND SUPPLIES**

- Ratchet
- 10 mm Socket
- 19 mm Open end wrench
- 5 mm and 9 mm Hex wrenches
- Torque wrench
- · Masking tape
- Drill
- 3 mm, 6 mm, and 9 mm Drill bits
- Center punch
- File
- · Felt-tip pen
- Eye protection (face shield, safety goggles, etc.)

The following tool is available through the Honda Tool and Equipment Program: 6 mm Long Rivet Nut Tool (T/N 07AAE-STX-A100)

### **INSTALLATION**

### Installing the Scuff Plate


Remove the bolts.








2 Loosely install the scuff plate.



- SCUFF PLATE (Ensure alignment of scuff plate contour to body contours.)
  - SHOULDER BOLT (Loosely secure.)(3)


3 Loosely secure the scuff plate.







Mark the front bumper.





A		FELT-TIP PEN
Œ		HOLE(4)
A	\	Mark the center of the hole.(4)

**5** Mark the front bumper.



Set the center punch to the minimum setting, as the body may be deformed.






Remove the scuff plate.


Drill the front bumper.





A	MASKING TAPE
B	MARK(4)
0	DRILL BITS


8 Install the rivet nuts.



<b>G</b>		RIVET NUT(4)
Œ		6 mm LONG RIVET NUT TOOL
	•	MANDREL

QPD0301AD

Insert the rivet nuts.




9 mm HOLE(4)

10 Secure the rivet nuts.


#### **S** NOTE

- Be careful not to overtighten the rivet nut.
- To fully seat the rivet nuts. Turn the rivet nut tool 3 full turns, then thread the shank of the rivet nut tool till threads are flush with the nut. Then turn 2 full turns to full seat the rivet nut.



A	9 mm HEX WRENCH
B	19 mm OPEN END WRENCH
0	FRONT BUMPER
D	RIVET NUT
<b>B</b>	MANDREL


Remove the 6 mm long rivet nut tool.



12 Loosely install the scuff plate.




Confirm scuff plate molding is not deformed.




A	SCUFF PLATE MOLDING
В	SCUFF PLATE
0	FRONT BUMPER
А	SCUFF PLATE (Ensure alignment of scuff plate contour to body contours.)
В	SHOULDER BOLT (Loosely secure.)(3)

QP70206AD

13 Loosely secure the scuff plate.






Secure the scuff plate.



Work in the order shown.



Ensure alignment of scuff plate contour to body contours.
BOLT(4)
SHOULDER BOLT(3)

15 Check that all parts are installed properly.